



1. Power switch on.

### Entering your student ID

1. After a few seconds, autoscan will begin. Press the menu button (\*) to stop it.
2. Press the menu button (\*) again to go to the Setup menu.
3. Press the up triangle to go to Setup menu / ID:
4. Press the enter button.
5. Enter your student ID using the number pad. Use the backspace button to correct any mistakes.
6. Press the enter button to store your ID.

### Joining the class

1. Press the menu button (\*) to go to New class scan.
2. Press the enter button to begin scanning for your class.
3. If you know the channel for your class, press that number or letter during the scan and your clicker will locate your class. Click the enter button to join the class.
4. The top line of the screen should read: ANS: The bottom line shows the name of your class.

### Answering questions

1. When the question is released, select your answer using the letter or number buttons. Click the enter button to submit your answer. The display will show that the answer has been received.
2. For the next question you can overwrite the previous answer or press the backspace button to erase the previous answer.
3. Press the decimal point twice for a forward slash (/).
4. Press the decimal point 3 times for a space in your answer.
5. The PRS will turn itself off after about a minute. Press any button to turn it back on again.