

Classroom AV

Turn on the projector

Locate the Crestron control panel.
It may be mounted on the wall,
or on a piece of plywood on the AV cabinet.
Press and hold the PC button for about 4 seconds.
The projector will beep and its light will come on.



Connect your laptop

There's a long bundle of cables in or near the AV cabinet.
Plug the VGA cable into the external monitor port on your laptop.
Turn on your laptop. (*see options below)
If the computer image doesn't appear on the screen:
Press Fn-F7 (thinkpad)



*options to consider before turning on your laptop:
connect network cable for internet access (or use wireless)
connect audio cable to headphone jack on laptop for sound
connect AC adapter to extension cord

Playing a VHS or DVD

Press VIDEO on the Crestron control panel
Locate VHS/DVD player in cabinet and turn it on.
Insert tape or disc and press play.
Volume is controlled using the dial on the Crestron panel.



<http://www.okanagan.bc.ca/administration/itservices/edtech/av.html>